

OTHER SIZE SOLENOID COIL DATA 线圈数据

Coil Must Be Installed With Lettering Up 安装线圈时,字母必须朝上。

Unit=Millimeters









